



Be Sure to leave a large radius at the end of the cut

If you purchased an Evolution Tower for use on an existing foil please refer to this diagram to modify the top of your strut so it fits into the tower correctly.

To clear the rear brace on your new Evo Tower your Tbar must be modified to fit.

The short cut is for a std Pro Tbar with only 2 holes in the strut.

The long cut is for the Launch Tbar with 6 holes in the strut.

This modification can be done with simple hand tools or if you want to send in your Tbar we will do the Modification at no charge.

Fork Top LE should use 3 Bolts to prevent tbar from moving in tower
cut material to remove approximately 5/8" x 1-7/8"

A
Full Scale
cutout for tracing